

Important: This connection schematics and the associated configuration form are just suggestions based on the data available to us. Your sensors may be different and they may require different schematics and form. Please refer to the Daqu manual for more details.

